

SLOPED ROOF CURB INSTALLATION INSTRUCTIONS

**** BEFORE STARTING YOUR ****
***** INSTALLATION! *****

**MAKE SURE THAT THE UNIT YOU ARE INSTALLING
MATCHES THE CURB YOU HAVE RECEIVED; OTHERWISE
YOUR UNIT WILL NOT FIT THIS CURB!**

For exact model specific instructions please contact MGM Products

SLOPED ROOF CURB DESCRIPTION

**Your curb will be prefabricated with duct supports
and a wooden nailer. You also should have
received gasket for the top of the curb.**

INSTRUCTIONS

- 1) Unpack the curb and locate all parts.
 - a. Is the curb the correct size for your RTU?
 - b. Locate the gasket.
 - c. Is the slope correct?
 - d. Is the slope direction correct?
- 2) Place the roof curb on the roof in the specified location.
- 3) Attach the curb per the engineer's specification. If a specification is not provided use #10 tek screws or stitch welds a minimum of (1) per corner and 16" on center around perimeter.
- 4) Install gasket material around top perimeter of curb and on top of all duct walls.
- 5) You should now be ready to roof in your curb. If you have any questions or problems, please call MGM Products, Inc.

MGM PRODUCTS, INC.

1080 CULPEPPER DRIVE CONYERS, GA 30094
(770) 483-0055 (800) 341-3536 Fax: (770) 483-0130